










Installation Manual				
Parts list				
No.	ITEM	SPECS	QUANTITY	
A			16	
B			16	
C		M6	1	
D		M4	1	
F		M2. 5	1	
G			2	
H			4	
I			1	
J		M8*90	1	
K			1	
No.	ITEM	SPECS	QUANTITY	
A			16	
B			16	
C		M6	1	
D		M4	1	
F		M2. 5	1	
G			2	
H			4	
I			1	
J		M8*90	1	
K			1	
No.	ITEM	SPECS	QUANTITY	
A			16	
B			16	
C		M6	1	
D		M4	1	
F		M2. 5	1	
G			2	
H			4	
I			1	
J		M8*90	1	
K			1	

Installation Manual				
Parts list				
No.	ITEM	SPECS	QUANTITY	
A			16	
B			16	
C		M6	1	
D		M4	1	
E		M3	1	
F		M2. 5	1	
G			2	
H			4	
I			1	
L		set screws M6*6	1	
M			1	
N		M8*160	1	
No.	ITEM	SPECS	QUANTITY	
A			16	
B			16	
C		M6	1	
D		M4	1	
E		M3	1	
F		M2. 5	1	
G			2	
H			4	
I			1	
L		set screws M6*6	1	
M			1	
N		M8*160	1	
No.	ITEM	SPECS	QUANTITY	
A			16	
B			16	
C		M6	1	
D		M4	1	
E		M3	1	
F		M2. 5	1	
G			2	
H			4	
I			1	
L		set screws M6*6	1	
M			1	
N		M8*160	1	


Installation Manual						
Parts list						
No.	ITEM	SPECS	QUANTITY			
A			16			
B			16			
C		M6	1			
D		M4	1			
E		M3	1			
F		M2. 5	1			
G			2			
H			4			
I			1			
L		set screws M6*6	1			
M			1			
N		M8*160	1			
No.	ITEM	SPECS	QUANTITY			
A			16			
B			16			
C		M6	1			
D		M4	1			
E		M3	1			
F		M2. 5	1			
G			2			
H			4			
I			1			
L		set screws M6*6	1			
M			1			
N		M8*160	1			
No.	ITEM	SPECS	QUANTITY			
A			16			
B			16			
C		M6	1			
D		M4	1			
E		M3	1			
F		M2. 5	1			
G			2			
H			4			
I			1			
L		set screws M6*6	1			
M			1			
N		M8*160	1			

Installation Manual

Clamp Installation


I

Desk Clamp



Clamp range: 15mm-50mm

Thru-Desk




hole: >=8.5mm

Desk thickness: 10mm-50mm


II

Desk Clamp



Clamp range: 15mm-50mm

Thru-Desk




hole: >=8.5mm

Desk thickness: 10mm-50mm


III

Desk Clamp



Clamp range: 15mm-50mm

Thru-Desk





hole: >=8.5mm


Desk thickness: 10mm-50mm


Installation Manual

Arm Installation









Installation Manual

Arm Installation

